### PLAYING INSTRUCTIONS 4 PAK

All Action cartridge into the control deck

EASE NOTE: To begin a new game during play, turn the power.
T. Then switch it ON again and select degred game.

1. TWIN MOUSE

into post mund

(ii) Speed slows down if you try to jump while walking through water

## CONTROL

\* Button 1 or 2 - Start Game flutton 2 - Justo

2 DOWED BLOCK

partypes of the end of each round there is a least and obtain a force sheeld to enter into nex

(ii) Player 2 can join in at any time by pressing "Start" on control 2, even while player 1 is playing the come.

CONTROL - Bullion 1 or 2 - Start Game

Fire mode (once force shield is of

### (i) For one player only (ii) Both vertical & horizontal scroll is possible (iii) You can double jump if power is graned during play.

(iii) For can obtain jump it power is granted during play.(iv) Speed slows down if you try to jump white walking through water.

# CONTROL

\* Button 1 or 2 - Start Game \* Button 1 - Attack

3. CAVE DUDE

Button 2 - Jump
 Left/Fight Direction Button
 Down button - Side down hill
(impact on energy when collided)

4. ADVENTURE KID

For one player only.
 These are 7 worlds to venture, each world consists of 4 entering the street of the second consists.

stages iii) Your mission is to find the map in each stage. iv) Bonus points am gained if the key is found during the qu v). The key will appear when you attack any of the designat places.

GONTROL

\* Button 1 or 2 - Start Game

Button 1 - Jump
 Button 2 - Attack
 Left Plight Directon Button

HOME ENTERTAINMENT SUPPLIERS PTY LTD UNIT 492 BYVANT STREET PROSTOW NSW 2211 AUSTRALIA